


FROM POWER SOURCE SYSTEM (SEE PAGE 52)

* 1 : W/ DOOR LOCK CONTROL
* 2 : W/O DOOR LOCK CONTROL



SERVICE HINTS

HORN RELAY

5-3 : Closed with the horn SW on

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B6	36	H5	34 (2ZZ-GE)	J8	37
C16	36	H6	32 (1ZZ-FE)		
H5	32 (1ZZ-FE)		34 (2ZZ-GE)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2D	23	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2F		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE5	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Brace LH)