

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Condenser Fan Motor	90980-11410	D 2	Door Control Receiver	90980-11909
A 2	A/C Magnetic Clutch and Lock Sensor	90980-11016	D 3	Door Courtesy SW LH	90980-10871
A 3	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	D 4	Door Courtesy SW RH	
A 4	ABS Actuator	90980-10891	D 5	Door Lock Motor , Door Lock Detection SW and Door Key Lock and Unlock SW LH	90980-11858
A 5	ABS Actuator	90980-11413	D 6	Door Lock Motor , Door Lock Detection SW and Door Key Lock and Unlock SW RH	
A 6	ABS Speed Sensor Front LH	90980-11003	D 7	Door Side Airbag Sensor LH	90980-11856
A 7	ABS Speed Sensor Front RH		D 8	Door Side Airbag Sensor RH	
A 8	A/C Evaporator Temp. Sensor	90980-11918	D 9	Daytime Running Light Resistor	90980-10928
A 9	A/C SW	90980-11923	E 1	Electronically Controlled Transmission Solenoid	90980-11658
A10	ABS ECU	90980-11424	E 2	Engine Control Module	90980-11638
A11	ABS ECU	90980-11390	E 3	Engine Control Module	90980-11637
A12	Airbag Squib (Front Passenger Airbag Assembly)	90980-11884	E 4	Engine Control Module	90980-11476
A13	Airbag Squib (Steering Wheel Pad)		E 5	Engine Control Module	90980-11421
A14	Automatic Light Control Sensor	90980-11107	E 6	Engine Coolant Temp. Sensor	90980-11062
A15	ABS Speed Sensor Rear LH	90980-11060	E 7	Oil Pressure SW (VVTL)	90980-11363
A16	ABS Speed Sensor Rear RH		F 1	Front Airbag Sensor LH	90980-11898
B 1	Back-Up Light SW	90980-11051	F 2	Front Airbag Sensor RH	
B 2	Brake Fluid Level Warning SW	90980-11207	F 3	Front Fog Light LH	90980-11003
B 3	Blower Motor	90980-10214	F 4	Front Fog Light RH	
B 4	Blower Resistor	90980-11136	F 5	Front Parking Light LH	90980-11156
B 5	Blower SW	90980-10877	F 6	Front Parking Light RH	
B 6	Body ECU	90980-11877	F 7	Front Side Marker Light LH	90980-11162
B 7	Body ECU	90980-11915	F 8	Front Side Marker Light RH	
B 8	Buckle SW LH	90980-10795	F 9	Front Turn Signal Light LH	90980-11019
B 9	Buckle SW RH		F10	Front Turn Signal Light RH	
B10	Back Door Lock Motor		F11	Front Wiper Motor	90980-11599
C 1	Camshaft Position Sensor	90980-10947	F12	Front Fog Light Relay	82660-20340
C 2	Camshaft Timing Oil Control Valve (VVL)	90980-11162	F13	Front Door Speaker LH	90980-10935
C 3	Camshaft Timing Oil Control Valve (VVT)		F14	Front Door Speaker RH	
C 4	Crankshaft Position Sensor	90980-10947	F15	Front Door Tweeter Speaker LH	90980-10915
C 5	Cruise Control Actuator	90980-11150	F16	Front Door Tweeter Speaker RH	
C 6	Center Airbag Sensor Assembly	90980-11872	F17	Fuel Sender and Pump	90980-11077
C 7	Center Airbag Sensor Assembly	90980-11869	G 1	Generator	90980-09212
C 8	Center Airbag Sensor Assembly	90980-11867	G 2	Generator	90980-11349
C 9	Cigarette Lighter	90980-10795	G 3	Glove Box Light and SW	90980-11098
C10	Clock	90980-10789	H 1	Headlight LH (High)	90980-11659
C11	Clutch Start SW	90980-10825	H 2	Headlight LH (Low)	90980-10481
C12	Combination Meter	90980-11915	H 3	Headlight RH (High)	90980-11659
C13	Combination Meter	90980-11913	H 4	Headlight RH (Low)	90980-10481
C14	Combination SW	90980-11594	H 5	Horn (High)	90980-10619
C15	Combination SW	90980-11672	H 6	Horn (Low)	
C16	Combination SW	90980-11986	H 7	Hazard SW	90980-10801
C17	Cruise Control Clutch SW	90980-10906	H 8	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
C18	Cruise Control ECU	90980-11391	H 9	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028
D 1	Data Link Connector 3	90980-11665			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
H10	High Mounted Stop Light	90980-10859	P 7	Power Window Motor LH	90980-10860
I 1	Idle Air Control Valve	90980-11145	P 8	Power Window Motor RH	
I 2	Ignition Coil and Igniter No.1	90980-11885	P 9	Pretensioner LH	90980-11862
I 3	Ignition Coil and Igniter No.2		P10	Pretensioner RH	
I 4	Ignition Coil and Igniter No.3		R 1	Radiator Fan Motor	90980-10928
I 5	Ignition Coil and Igniter No.4		R 2	Radio and Player	90980-10997
I 6	Injector No.1	90980-11875	R 3	Radio and Player	90980-10996
I 7	Injector No.2		R 4	Radio and Player	90980-12038
I 8	Injector No.3		R 5	Rheostat	90980-10908
I 9	Injector No.4		R 6	Rear Combination Light LH	90980-11011
I10	Ignition SW	90980-11778	R 7	Rear Combination Light RH	
J 1	Junction Connector	90980-10803	R 8	Rear Speaker LH	90980-10935
J 2	Junction Connector	90980-11542	R 9	Rear Speaker RH	
J 3	Junction Connector	90980-11686	R10	Rear Window Defogger	90980-10913
J 4	Junction Connector	90980-11661	R11	Rear Window Defogger	90980-10914
J 5	Junction Connector		R12	Rear Wiper Motor and Relay	90980-10908
J 6	Junction Connector	90980-11915	R13	Remote Control Mirror LH	90980-11587
J 7	Junction Connector	90980-11542	R14	Remote Control Mirror RH	
J 8	Junction Connector	90980-11915	R15	Remote Control Mirror SW	90980-11657
J 9	Junction Connector	90980-11542	S 1	Starter	90980-11400
J10	Junction Connector	90980-11686	S 2	Starter	90980-09506
J11	Junction Connector	90980-11542	S 3	Shift Lock Control ECU	90980-11909
J12	Junction Connector	90980-11661	S 4	Side Airbag Squib LH	90980-11864
J13	Junction Connector		S 5	Side Airbag Squib RH	
J14	Junction Connector	90980-11686	S 6	Stereo Component Amplifier	90980-10848
K 1	Knock Sensor (1ZZ-FE)	90980-11166	S 7	Stereo Component Amplifier	90980-11913
	Knock Sensor (2ZZ-GE)	90980-11875	S 8	Stop Light SW	90980-11118
L 1	License Plate Light LH	90980-11148	S 9	Side Airbag Sensor LH	90980-11857
L 2	License Plate Light RH		S10	Side Airbag Sensor RH	
L 3	Luggage Compartment Light	90980-10121	T 1	Throttle Position Sensor	90980-11261
L 4	Luggage Compartment Light SW	90980-10871	T 2	Turn Signal Flasher Relay	82751-07010
M 1	Mass Air Flow Meter	90980-11317	T 3	Tension Reducer Solenoid LH	90980-11369
M 2	Moon Roof Control Relay and Motor	90980-10997	T 4	Tension Reducer Solenoid RH	
M 3	Moon Roof Control SW and Personal Light	90980-11533	U 1	Unlock Warning SW	90980-10860
N 1	Noise Filter (Ignition System)	90980-11156	V 1	Vehicle Speed Sensor (Combination Meter)	90980-11143
N 2	Noise Filter (Rear Window Defogger)	90980-10825	V 2	Vehicle Speed Sensor (Electronically Controlled Transmission)	90980-11156
O 1	O/D Direct Clutch Speed Sensor	90980-11156	V 3	VSV (ACIS)	
O 2	Oil Pressure SW	90980-11363	V 4	VSV (Canister Closed Valve)	90980-11162
O 3	O/D Main SW	90980-11011	V 5	VSV (EVAP)	90980-11156
P 1	Park/Neutral Position SW	90980-11784	V 6	Vapor Pressure Sensor	90980-11143
P 2	Power Steering Oil Pressure SW	90980-11428	V 7	VSV (Pressure Switching Valve)	90980-11859
P 3	Parking Brake SW	90980-10871	W 1	Washer Motor	90980-10981
P 4	Power Window Lock SW	90980-10997	W 2	Woofer Speaker LH	90980-10795
P 5	Power Window Master SW	90980-11973	W 3	Woofer Speaker RH	
P 6	Personal Light (w/o Moon Roof)	90980-11148			