

## Diagram Information and Instructions

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Condenser Fan Motor	90980-11410	D 2	Door Control Receiver	90980-11909
A 2	A/C Magnetic Clutch and Lock Sensor	90980-11016	D 3	Door Courtesy SW LH	90980-10871
A 3	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	D 4	Door Courtesy SW RH	
A 4	ABS Actuator	90980-10891	D 5	Door Lock Motor , Door Lock Detection SW and Door Key Lock and Unlock SW LH	90980-11858
A 5	ABS Actuator	90980-11413	D 6	Door Lock Motor , Door Lock Detection SW and Door Key Lock and Unlock SW RH	
A 6	ABS Speed Sensor Front LH	90980-11003	D 7	Door Side Airbag Sensor LH	90980-11856
A 7	ABS Speed Sensor Front RH		D 8	Door Side Airbag Sensor RH	
A 8	A/C Evaporator Temp. Sensor	90980-11918	E 1	Electronically Controlled Transmission Solenoid	90980-11658
A 9	A/C SW	90980-11923	E 2	Engine Control Module	90980-11638
A10	ABS ECU	90980-11424	E 3	Engine Control Module	90980-11637
A11	ABS ECU	90980-11390	E 4	Engine Control Module	90980-11476
A12	Airbag Squib (Front Passenger Airbag Assembly)	90980-11884	E 5	Engine Control Module	90980-11421
A13	Airbag Squib (Steering Wheel Pad)		E 6	Engine Coolant Temp. Sensor	90980-11062
A14	Automatic Light Control Sensor	90980-11107	E 7	Engine Oil Level Warning SW	90980-11363
A15	ABS Speed Sensor Rear LH	90980-11060	F 1	Front Airbag Sensor LH	90980-11898
A16	ABS Speed Sensor Rear RH		F 2	Front Airbag Sensor RH	
B 1	Back-Up Light SW	90980-11051	F 3	Front Fog Light LH	90980-11003
B 2	Brake Fluid Level Warning SW	90980-11207	F 4	Front Fog Light RH	
B 3	Blower Motor	90980-10214	F 5	Front Parking Light LH	90980-11156
B 4	Blower Resistor	90980-11136	F 6	Front Parking Light RH	
B 5	Blower SW	90980-10877	F 7	Front Side Marker Light LH	90980-11162
B 6	Body ECU	90980-11877	F 8	Front Side Marker Light RH	
B 7	Body ECU	90980-11915	F 9	Front Turn Signal Light LH	90980-11019
B 8	Buckle SW LH	90980-10795	F10	Front Turn Signal Light RH	
B 9	Buckle SW RH		F11	Front Wiper Motor	90980-11599
B10	Back Door Lock Motor		F12	Front Fog Light Relay	82660-20340
C 1	Camshaft Position Sensor	90980-10947	F13	Front Door Speaker LH	90980-10935
C 2	Camshaft Timing Oil Control Valve (VVL)	90980-11162	F14	Front Door Speaker RH	
C 3	Camshaft Timing Oil Control Valve (VVT)		F15	Front Door Tweeter Speaker LH	90980-10915
C 4	Crankshaft Position Sensor	90980-10947	F16	Front Door Tweeter Speaker RH	
C 5	Cruise Control Actuator	90980-11150	F17	Fuel Sender and Pump	90980-11077
C 6	Center Airbag Sensor Assembly	90980-11872	G 1	Generator (2ZZ-GE)	90980-09212
C 7	Center Airbag Sensor Assembly	90980-11869		Generator (1ZZ-FE)	90980-09213
C 8	Center Airbag Sensor Assembly	90980-11867	G 2	Generator	90980-11349
C 9	Cigarette Lighter	90980-10795	G 3	Glove Box Light and SW	90980-11098
C10	Clock	90980-10789	H 1	Headlight LH (High)	90980-11659
C11	Clutch Start SW	90980-10825	H 2	Headlight LH (Low)	90980-10481
C12	Combination Meter	90980-11915	H 3	Headlight RH (High)	90980-11659
C13	Combination Meter	90980-11913	H 4	Headlight RH (Low)	90980-10481
C14	Combination SW	90980-11594	H 5	Horn (High)	90980-10619
C15	Combination SW	90980-11672	H 6	Horn (Low)	
C16	Combination SW	90980-11986	H 7	Hazard SW	90980-10801
C17	Cruise Control Clutch SW	90980-10906	H 8	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
C18	Cruise Control ECU	90980-11391	H 9	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028
D 1	Data Link Connector 3	90980-11665			

ZOOM

SIZED FOR PRINT

Code	Part Name	Part Number	Code	Part Name	Part Number
H10	High Mounted Stop Light	90980-10859	P 7	Power Window Motor LH	90980-10860
I 1	Idle Air Control Valve	90980-11145	P 8	Power Window Motor RH	
I 2	Ignition Coil and Igniter No.1	90980-11885	P 9	Pretensioner LH	90980-11862
I 3	Ignition Coil and Igniter No.2		P10	Pretensioner RH	
I 4	Ignition Coil and Igniter No.3		R 1	Radiator Fan Motor	90980-10928
I 5	Ignition Coil and Igniter No.4		R 2	Radio and Player	90980-10997
I 6	Injector No.1	90980-11875	R 3	Radio and Player	90980-10996
I 7	Injector No.2		R 4	Radio and Player	90980-12038
I 8	Injector No.3		R 5	Rheostat	90980-10908
I 9	Injector No.4		R 6	Rear Combination Light LH	90980-11011
I10	Ignition SW	90980-11778	R 7	Rear Combination Light RH	
J 1	Junction Connector	90980-10803	R 8	Rear Speaker LH	90980-10935
J 2	Junction Connector	90980-11542	R 9	Rear Speaker RH	
J 3	Junction Connector	90980-11686	R10	Rear Window Defogger	90980-10913
J 4	Junction Connector	90980-11661	R11	Rear Window Defogger	90980-10914
J 5	Junction Connector		R12	Rear Wiper Motor and Relay	90980-10908
J 6	Junction Connector	90980-11915	R13	Remote Control Mirror LH	90980-11587
J 7	Junction Connector	90980-11542	R14	Remote Control Mirror RH	
J 8	Junction Connector	90980-11915	R15	Remote Control Mirror SW	90980-11657
J 9	Junction Connector	90980-11542	S 1	Starter	90980-11400
J10	Junction Connector	90980-11686	S 2	Starter	90980-09506
J11	Junction Connector	90980-11542	S 3	Shift Lock Control ECU	90980-11909
J12	Junction Connector	90980-11661	S 4	Side Airbag Squib LH	90980-11864
J13	Junction Connector		S 5	Side Airbag Squib RH	
J14	Junction Connector	90980-11686	S 6	Stereo Component Amplifier	90980-10848
K 1	Knock Sensor	90980-11166	S 7	Stereo Component Amplifier	90980-11913
L 1	License Plate Light LH	90980-11148	S 8	Stop Light SW	90980-11118
L 2	License Plate Light RH		S 9	Side Airbag Sensor LH	90980-11857
L 3	Luggage Compartment Light	90980-10121	S10	Side Airbag Sensor RH	
L 4	Luggage Compartment Light SW	90980-10871	T 1	Throttle Position Sensor	90980-11261
M 1	Mass Air Flow Meter	90980-11317	T 2	Turn Signal Flasher Relay	82751-07010
M 2	Moon Roof Control Relay and Motor	90980-10997	T 3	Tension Reducer Solenoid LH	90980-11369
M 3	Moon Roof Control SW and Personal Light	90980-11533	T 4	Tension Reducer Solenoid RH	
N 1	Noise Filter (Ignition System)	90980-11156	U 1	Unlock Warning SW	90980-10860
N 2	Noise Filter (Rear Window Defogger)	90980-10825	V 1	Vehicle Speed Sensor (Combination Meter)	90980-11143
O 1	O/D Direct Clutch Speed Sensor	90980-11156	V 2	Vehicle Speed Sensor (Electronically Controlled Transmission)	90980-11156
O 2	Oil Pressure SW	90980-11363	V 3	VSV (ACIS)	
O 3	O/D Main SW	90980-11011	V 4	VSV (Canister Closed Valve)	
P 1	Park/Neutral Position SW	90980-11784	V 5	VSV (EVAP)	90980-11156
P 2	Power Steering Oil Pressure SW	90980-11428	V 6	Vapor Pressure Sensor	90980-11143
P 3	Parking Brake SW	90980-10871	V 7	VSV (Pressure Switching Valve)	90980-11859
P 4	Power Window Lock SW	90980-10997	W 1	Washer Motor	90980-10981
P 5	Power Window Master SW	90980-11973	W 2	Woofer Speaker LH	90980-10795
P 6	Personal Light (w/o Moon Roof)	90980-11148	W 3	Woofer Speaker RH	

ZOOM

SIZED FOR PRINT