


ADJUSTMENT

1. ADJUST HEADLIGHT AIMING



2. ADJUST SPIRAL CABLE (See page [SR-12](#))