

## INSTALLATION

### 1. INSTALL FRONT SEAT

- (a) Slide the front seat to the frontmost position.

**NOTICE:**

**Make sure that seat adjuster locks.**

- (b) Without holding the seat track handle, mount the seat to the vehicle.

**HINT:**

If holding the seat track handle, the adjusted frontmost positions slip off.

- (c) Tighten the bolts on the rear side temporarily, then tighten them completely starting from the bolt on the inner side.

**Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)**

- (d) Slide the seat to the rearmost position to install the bolts on the front side.

**Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)**

- (e) Connect the connectors.

### 2. INSTALL SEAT TRACK COVERS