

## REMOVAL

### REMOVE FRONT SEAT

- (a) Using a screwdriver, remove the seat track covers.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 4 bolts.  
(c) Remove the front seat.

### NOTICE:

**Be careful not to damage the body.**