

INSTALLATION

Installation is in the reverse order of removal (See Page [BR-10](#)).

1. BEFORE INSTALLATION, ADJUST LENGTH OF BRAKE BOOSTER PUSH ROD (See page [BR-18](#))
2. AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)) AND CHECK FOR LEAKS.
3. CHECK AND ADJUST BRAKE PEDAL (See page [BR-5](#))