


TERMINALS OF ECM


1. w/o Front Passenger Airbag Assembly



W05581

No.	Symbol	Terminal Name
A	–	Electrical Connection Check Mechanism
B	–	Electrical Connection Check Mechanism
1	P ⁻	D squib ⊖
2	P ⁺	D squib ⊕
3	E ₁	Ground
4	E ₂	Ground
5	T _c	Diagnosis
6	LA	SRS Warning Light
7	IG ₂	Power Source (IGN Fuse)
8	ACC	Power Source (CIG Fuse)

2. w/ Front Passenger Airbag Assembly



W05580

No.	Symbol	Terminal Name
A	–	Electrical Connection Check Mechanism
B	–	Electrical Connection Check Mechanism
1	P ⁻	Squib ⊖ (Passenger)
2	P ⁺	Squib ⊕ (Passenger)
3	D ⁻	Squib ⊖ (Driver)
4	D ⁺	Squib ⊕ (Driver)
5	E ₁	Ground
6	E ₂	Ground
7	T _c	Diagnosis
8	LA	SRS Warning Light
9	IG ₂	Power Source (IGN Fuse)
10	ACC	Power Source (CIG Fuse)