


Door Courtesy Switch Circuit

CIRCUIT DESCRIPTION

The door courtesy switch goes on when the door is opened and goes off when the door is closed.

WIRING DIAGRAM



N16787

INSPECTION PROCEDURE

- 1 Check operation of open door warning light.

CHECK:

Check that open door warning light comes on when each door is opened, and goes off when all doors are closed.

NG

Check and repair open door warning light circuit.

OK

2	Check for open in harness and connector between theft deterrent ECU and door courtesy switch (See page IN-27).
---	---

OK**Check and replace theft deterrent ECU. *1****NG****Repair or replace harness or connector.**

*1: When there is a malfunction that the theft deterrent system cannot be set, proceed to the next numbered circuit inspection shown on matrix chart (See page [DI-273](#)).