



BODY INSPECTION

MA02M-04

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

Tighten these parts:

- Front seat mount bolts

Torque: 37 N·m (375 kgf-cm, 27 ft-lbf)

Under Severe Conditions:

In addition to the above maintenance items, check for loose or missing nuts and bolts on the following:

- Steering system
- Drive train
- Suspension system
- Fuel tank mounts
- Engine mounts, etc.

2. FINAL INSPECTION

(a) Check the operation of the body parts:

- Hood:
Auxiliary catch operates properly
Hood locks securely when closed
- Front and rear doors:
Door lock operates properly
Doors close properly
- Luggage compartment door:
Door lock operates properly
- Seats:
Seat adjusts easily and locks securely in any position
Front seat back locks securely in any position
Folding-down rear seat backs lock securely

(b) Road test:

- Check the engine and chassis for abnormal noises.
- Check that the vehicle does not wander or pull to one side.
- Check that the brakes work properly and do not drag.

(c) Be sure to deliver a clean vehicle especially check:

- Steering wheel
- Shift lever knob
- All switch knobs
- Door handles
- Seats