


























# SUSPENSION AND AXLE

## SST (Special Service Tools)

PP16G-03

	09223-15020 Oil Seal & Bearing Replacer	Front axle
	09308-00010 Oil Seal Puller	Front axle Rear axle
	09309-36010 Transmission Rear Bearing Replacer	Front drive shaft
	09316-20011 Transfer Bearing Replacer	Front drive shaft
	09520-00031 Rear Axle Shaft Puller	Front axle
	09550-10012 Replacer Set "B"	Rear axle
	(09552-10010) No. 2 Replacer Handle-	
	(09553-10010) Differential Side Bearing Replacer	
	(09557-10010) Differential Drive Pinion Front Bearing Replacer	
	09608-10010 Steering Knuckle Oil Seal Replacer	Front axle
	09608-16042 Front Hub Bearing Adjusting Tool	Front drive shaft
	(09608-02021) Bolt & Nut	

	(09608-02041) Retainer	
	09628-10011 Ball Joint Puller	Front axle
	09628-62011 Ball Joint Puller	Front axle Front suspension
	09631-12040 Oil Seal "A" Replacer	Front axle
	09727-30021 Coil Spring Compressor	Front suspension Rear suspension
	09751-36011 Brake Line Union Nut 10 x 12 mm Wrench	Rear axle
	09950-00020 Bearing Remover	Front axle Front drive shaft
	09950-60010 Replacer Set	
	(09951-00460) Replacer 46	Rear axle
	(09951-00610) Replacer 61	Front axle
	(09951-00650) Replacer 65	Front axle
	09950-70010 Handle Set	Front axle Rear axle
	(09951-07150) Handle 150	