







STARTING

SST (Special Service Tools)

PP201-01

	09221-25026	Piston Pin Remover & Replacer	
	(09221-00071)	Guide "A"	Center bearing for planetary type
	(09221-00090)	Guide "C"	Center bearing for planetary type
	09286-46011	Injection Pump Spline Shaft Puller	Armature bearing for reduction type
	09820-00030	Alternator Rear Bearing Replacer	Armature rear bearing for reduction type
	09810-38140	Starter Magnet Switch Nut Wrench 14	Terminal nut