

INSTALLATION

Installation is in the reverse order of removal (See page [SA-58](#)).

AFTER INSTALLATION, BLEED BRAKE SYSTEM (See page [BR-4](#)) AND CHECK ABS SPEED SENSOR SIGNAL (See page [DI-173](#))