

FUEL TANK AND LINE

SF0X6-01

PRECAUTION

1. Always use new gaskets when replacing the fuel tank or components parts.
2. Apply the proper torque to all parts tightened.