


INTAKE AIR TEMPERATURE (IAT) SENSOR COMPONENTS

SFOXR-01



S06529