

TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Oil pan drain plug	17	175	13
Oil pan	4.9	50	43 in.·lbf
Valve body x Oil strainer	10	100	7
Valve body x Oil pipe bracket	10	100	7
Valve body x Oil pipe clamp	10	100	7
Solenoid wire assembly clamp	10	100	7
Detent spring	10	100	7
Valve body x Transaxle case	10	100	7
Park/neutral position switch x Transaxle case (Bolt)	5.4	55	48 in.·lbf
Park/neutral position switch (Nut)	6.9	70	61 in.·lbf
Shift control cable x Transaxle control shaft lever	15	150	11
LH engine mounting bolt	64	650	47
LH engine mounting bracket set bolt	48	490	35
Starter set bolt	39	400	29
Transaxle housing x Engine (Upper side)	64	650	47
Intake manifold stay	20	200	14
Engine rear mounting bracket x Engine rear mounting insulator	64	650	47
Engine rear mounting insulator set bolt			
A bolt	78	800	58
B bolt	90	920	67
Transaxle housing x Engine (Lower side)			
A bolt	46	470	34
B bolt	8	76	66 in.·lbf
C bolt	39	400	29
D bolt	25	255	18
E bolt	64	650	47
Torque converter clutch x Drive plate	18	185	13
Drive plate x Crankshaft	90	900	65