

## TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Transaxle x Engine (See page <a href="#">MX-2</a> )			
17 mm head	64	650	47
14 mm head A:	46	470	34
14 mm head B:	24	240	17
10 mm head	7.4	75	65 in·lbf
Starter x Transaxle	39	400	29
Clutch release cylinder x Transaxle	12	120	9
Clutch line bracket x Transaxle	4.9	50	43 in·lbf
Front wheel	103	1,050	76
Front exhaust pipe clamp set bolt	32	325	24
Front exhaust pipe x Exhaust manifold	62	630	46
Front exhaust pipe x Exhaust tail pipe	19	195	14
Stabilizer bar bracket x Body	19	195	14
Engine rear mounting insulator x Bracket	64	650	47
Engine rear mounting insulator x Body	90	920	67
Steering member brace	78	800	58
Intake manifold stay	20	200	14
Engine left mounting bracket x Insulator	48	490	35
No.1 grommet retainer x Body	4.4	45	39 in·lbf
No.2 grommet retainer x Body	4.9	50	43 in·lbf
Shift lever assembly x Body	12	120	9
Output shaft front bearing lock plate set bolt	11	115	8
Transmission case x Transaxle case	29	300	22
Reverse shift arm bracket	17	175	13
Straight screw plug (Reverse restrict pin)	13	130	9
Straight screw plug (Shift fork shaft)	25	250	18
Straight screw plug (Lock ball assembly)	39	400	29
Reverse idler gear shaft lock bolt	29	300	22
Rear bearing retainer	27	280	20
Output shaft lock nut	118	1,200	87
Shift fork and shift head x Shift fork shaft	16	160	12
Shift and select lever assembly	20	200	14
Transmission case x Transmission case cover	18	185	13
Back-up light switch	40	410	30
Filler and drain plugs	39	400	29
Ring gear x Differential case	124	1,260	91
Speedometer driven gear	11	115	8
Clutch release fork support	37	375	27
Control lever housing support bracket x Transmission case	11	115	8
Selecting bellcrank assembly x Transmission case	25	250	18
Shift and select lever shaft assembly lock bolt	29	300	22
Transaxle case receiver x Transaxle case	11	115	8
Oil receiver pipe	17	175	13