

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
End cover x Brush holder		1.5	15	13 in.·lbf
End cover x Starter housing	Planetary type	5.9	60	52 in.·lbf
	Reduction type	9.3	95	82 in.·lbf
Magnetic switch x Starter housing	Planetary type	8.3	85	73 in.·lbf
	Reduction type	9.3	95	82 in.·lbf
Lead wire of field frame x Magnetic switch	Planetary type	9.8	100	87 in.·lbf
	Reduction type	5.9	60	52 in.·lbf
Intake manifold, cylinder block x Intake manifold stay		17.5	175	13
Starter wire x Terminal 30 of starter		8.8	90	78 in.·lbf
Starter x Transaxle		37	370	27
Terminal nut x Terminal C of starter, Terminal 30 of starter		17	173	12
Magnetic switch end cover x Magnetic switch		3.6	37	32 in.·lbf