



F RELAY LOCATIONS

[Engine Compartment]



[Instrument Panel]



- *1:w/ Theft Deterrent System,w/ Door Lock Control
 *2:w/ Theft Deterrent System,w/o Door Lock Control
 *3:w/o Theft Deterrent System,w/ Door Lock Control




F RELAY LOCATIONS

 : Driver Side J/B

Left Kick Panel (See Page 19)




[Driver Side J/B Inner Circuit]



F RELAY LOCATIONS

② : Engine Room R/B

Engine Compartment Left (See Page 18)



⑤ : Engine Room R/B No.5 Engine Compartment Left (See Page 18)
(Canada)

