



TRANSFER UNIT COMPONENTS

TR00X-01

**3RZ-FE M/T:
5VZ-FE M/T, A/T
(w/o One Touch 2-4 Selector System):**



M/T (w/ Diff. Lock, or/and ABS)


and A/T:
Transfer L4 Position Switch Connector

A/T:
Transfer Neutral Position Switch Connector




74 (750, 54)

74 (750, 54)



Extra Cab:




65 (660, 48)

N·m (kgf·cm, ft·lbf) : Specified torque


F01885

3RZ-FE A/T:



N·m (kgf·cm, ft·lbf) : Specified torque

**5VZ-FE M/T, A/T
(w/ One Touch 2-4 Selector System):**



N·m (kgf-cm, ft-lbf) : Specified torque