




INSTRUMENT PANEL COMPONENTS

B04QE-04




H24376



**Access Cab
Large Type Console Box**









T

Standard Cab
Access Cab
Double Cab



T

The shapes and sizes of the screws, bolts and nuts are indicated in the table below. The codes (A–H) correspond to those indicated in COMPONENTS on the previous pages.

mm (in.)								
Code	Shape	Size	Code	Shape	Size	Code	Shape	Size
Ⓐ		∅ = 6 (0.24) L = 25 (0.98)	Ⓑ		∅ = 6 (0.24) L = 14 (0.55)	Ⓒ		∅ = 8 (0.31) L = 22 (0.87)
Ⓓ		∅ = 5.22 (0.2055) L = 16 (0.63)	Ⓔ		∅ = 5 (0.20) L = 16 (0.63)	Ⓕ		∅ = 5 (0.20) L = 16 (0.63)
Ⓖ		∅ = 8 (0.31)	Ⓗ		∅ = 6 (0.24)			