



# RADIATOR

## ON-VEHICLE CLEANING

CO1C6-02

### INSPECT FINS FOR BLOCKAGE

If fins are clogged, wash them with water or a steam cleaner and dry with compressed air.

**NOTICE:**

- If the distance between the steam cleaner and the core is too close, there is a possibility of damaging the fin, so keep the following injection distance.

Injection Pressure	Injection Distance
2,942 to 4,903 kPa (30 to 80 kgf·cm <sup>2</sup> , 427 to 711 psi)	300 mm (11.81 in.)
4,903 to 7,845 kPa (50 to 80 kgf·cm <sup>2</sup> , 711 to 1,138 psi)	500 mm (19.69 in.)

- If the fins are bent, straighten them with a screwdriver or pliers.
- Never apply water directly onto the electronic components.