



## BRAKE INSPECTION

MA014-07

### 1. INSPECT BRAKE LINE PIPES AND HOSES

#### HINT:

Work in a well-lighted area. Check the entire circumference and length of the brake hoses using a mirror if necessary. Turn the front wheels fully to the right or left before beginning.

- (a) Check all the brake lines and hoses for:
  - Damage
  - Wear
  - Deformation
  - Cracks
  - Corrosion
  - Leaks
  - Bends
  - Twists
- (b) Check all the clamps for tightness and connections for leakage.
- (c) Check that the hoses and lines are not near sharp edges, moving parts and the exhaust system.
- (d) Check that the lines installed pass through the center of the grommets.

### 2. INSPECT FRONT BRAKE PADS AND DISCS

(See page [BR-44](#))

#### HINT:

If a squealing or scraping noise occurs from the brake during driving, check the pad wear indicator.

If there are traces of the indicator contacting the disc rotor, the disc pad should be replaced.

### 3. INSPECT REAR BRAKE LININGS AND DRUMS

(See page [BR-51](#))