

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the seat frame assembly or seatback cover with a new one.

Case	Replacing part
The side airbag has been deployed.	Seat assembly
The side airbag assembly has been found to be faulty in troubleshooting.	Seat frame assembly
The side airbag assembly has been found to have cuts while checking items (see page RS-52).	Seat frame assembly
The seatback cover has been found to have cuts and frayed seams while checking items (see page RS-52).	Seatback cover
The side airbag assembly has been found to be faulty while checking items (see page RS-52).	Seat frame assembly
The seatback cover has been found to be faulty while checking items (see page RS-52).	Seatback cover
The seatback assembly has been dropped.	Seat frame assembly

CAUTION:

For removal and installation of the seat frame assembly, see page RS-49 and RS-60. Be sure to follow the correct procedure.