

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the wire harness or connector with a new one.

- Any of the SRS wire harness and connectors has been found to be faulty in troubleshooting.
- Any of the SRS wire harness and connectors has been found to be faulty while checking items (see page [RS-141](#)).

CAUTION:

If the wire harness used in the SRS is damaged, replace the whole SRS wire harness assembly.