

TORQUE SPECIFICATION

| Part tightened | N·m | kgf·cm | ft·lbf |
|--|------|--------|------------|
| Rear propeller shaft x Rear differential | 88 | 897 | 65 |
| Center support bearing x Body | 40 | 410 | 30 |
| Rear propeller shaft x Transfer | 88 | 897 | 65 |
| Transfer x Transfer adaptor | 24 | 244 | 17 |
| Front propeller shaft x Front differential | 74 | 750 | 54 |
| Front propeller shaft x Transfer | 88 | 897 | 65 |
| Engine rear mounting x Transfer | 65 | 664 | 48 |
| Engine rear mounting x Crossmember | 18 | 185 | 13 |
| Crossmember x Frame | 72 | 740 | 53 |
| Heat insulator x Crossmember | 16 | 164 | 12 |
| Front exhaust pipe x Exhaust manifold | 62 | 630 | 46 |
| Filler plug x Transfer | 37 | 380 | 27 |
| Head screw plug x Transfer | 19 | 190 | 14 |
| Oil pump body x Front case | 7.5 | 76 | 66 in.·lbf |
| Separator with oil strainer x Front case | 7.5 | 76 | 66 in.·lbf |
| Transfer 4WD position switch | 37 | 377 | 27 |
| Transfer for L4 position switch | 37 | 377 | 27 |
| Actuator assembly set bolt | 20 | 204 | 15 |
| Shift fork shaft stopper set bolt | 19 | 190 | 14 |
| Straight screw plug | 19 | 190 | 14 |
| Front case x Rear case | 28 | 285 | 21 |
| Extension housing x Rear case | 12 | 122 | 9 |
| Front and rear companion flange lock nut | 118 | 1,203 | 87 |
| Upper cover x Front case | 18 | 184 | 13 |
| Front bearing retainer x Front case | 11.5 | 117 | 8 |
| Protector x Front case | 18 | 184 | 13 |
| Vehicle speed sensor assembly set bolt | 11 | 112 | 8 |