Illustrated Index

BRAKE BOOSTER
Do not disassemble
Testing, page 13-16
Pushrod Adjustment, page 13-17
Pushrod Clearance Adjustment, page 13-17

BRAKE PEDAL
Pedal Height Adjustment, page 13-4
Brake Light Switch Adjustment, page 13-4

MASTER CYLINDER
Index, page 13-11
Overhaul/Inspection, page 13-12
Disassembly, page 13-13
Reassembly, page 13-14

BRAKE HOSES/PIPES
Inspection, page 13-36
Brake Hoses Replacement, page 13-38



FRONT BRAKES
Inspection, page 13-5
Brake Pad Inspection/Replacement, page 13-6
Brake Caliper Disassembly/
Reassembly, page 13-7
Brake Disc Inspection, page 13-9
Bleeding, page 13-10

REAR BRAKE
DISC BRAKES
Inspection, page 13-19
Brake Pad Inspection/Replacement, page 13-21
Brake Caliper Disassembly, page 13-24
Brake Caliper Reassembly, page 13-27
BRAKE SHOES
Index and Inspection, page 13-31
Inspection, page 13-32
Disassembly, page 13-33
Reassembly, page 13-34
PARKING BRAKE
Adjustment, page 13-4
Disassembly and Reassembly, page 13-39