

HOW TO PROCEED WITH TROUBLESHOOTING

1 VEHICLE BROUGHT TO WORKSHOP

2 CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05-1181)

3 CHECK AND CLEAR DTCs (SEE PAGE 05-1192, 05-1195)

4 PROBLEM SYMPTOM CONFIRMATION

SYMPTOM DOES NOT OCCUR (Go to step 5)

SYMPTOM OCCURS (Go to step 6)

5 SYMPTOM SIMULATION (SEE PAGE 01-22)

6 CHECK DTC (SEE PAGE 05-1192)

DTC IS OUTPUT (Go to step 10)

DTC IS NOT OUTPUT (Go to step 7)

7 CHECK IF THE SAME SYMPTOM APPEARS IN THE NAVIGATION SYSTEM (SEE PAGE 05-1094)

The symptom appears (Follow the navigation symptom chart to perform troubleshooting) (see page 05-1094)

The symptom does not appear (Go to step 8)

8 PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1186)

The corresponding symptom exists (Go to step 10)

The corresponding symptom does not exist (Go to step 9)

9	BASED ON THE MALFUNCTION SYMPTOM, PERFORM TROUBLESHOOTING BELOW
---	---

(a) Terminals of ECU (see page 05-1187).



10	ADJUSTMENT, REPAIR OR REPLACE
----	-------------------------------



11	CONFIRMATION TEST
----	-------------------



END
