



Technical Service BULLETIN

August 10, 2001

Title:

SHOULDER BELT ANCHOR TAPE SET

Models:

All Applicable Models

BODY
B0019-01

Introduction To assist customers in preventing particle buildup and preserve the appearance of the shoulder belt anchor, the following procedure has been developed.

- Applicable Vehicles**
- 1996–2001 model year **4Runner**^{*1} vehicles.
 - 1996–2001 model year **Land Cruiser** vehicles.
 - 1996–2001 model year **RAV4**^{*2} vehicles.
 - 2001 model year **Sequoia** vehicles.
 - 1996–1998 model year **T100** trucks.
 - 1996–2001 model year **Tacoma**^{*1} trucks.
 - 2000–2001 model year **Tundra** trucks.

*1 Except rear seat belt.

*2 Except rear seat belt of soft top models.

Parts Information

CURRENT PART NUMBER	PART NAME
73205-48011	Tape Set, Shoulder Belt Anchor

NOTE:

The above tape set contains the fluorocarbon resin tape (2 pieces) and Velcro tape (1 piece).

Warranty Information

OP CODE	DESCRIPTION	TIME	OPN	T1	T2
BD1011	Clean the Shoulder Belt Anchor	0.3	73210-####-## ^{*1} 73220-####-## ^{*1}	61	99

*1 OPN should be part number of whichever belt assembly that the procedure is performed on.

Applicable Warranty*:

This repair is covered under the Toyota Comprehensive Warranty. This warranty is in effect for 36 months or 36,000 miles, whichever occurs first, from the vehicle's in-service date.


* Warranty application is limited to correction of a problem based upon a customer's specific complaint.



**Installation
Procedure****1. CLEAN SHOULDER BELT ANCHOR****NOTE:**


- Do not install the tape when the vehicle temperature is below the freezing point.
- Do not re-use removed fluorocarbon resin tape.

- A. Pull out the seat belt about 300 mm and attach a clip as shown in the illustration.


**HINT:**

Preventing the seat belt from retraction with a clip will make the following work easier.

- B. Put the Velcro tape (in the parts kit) through the hole of the shoulder belt anchor, brush-shaped side to the anchor.



- C. Pull both ends of the Velcro tape with your hand and shave off the dirt on the shoulder belt anchor by moving the Velcro tape several times as shown in the illustration.

**NOTE:**

Remove the dirt completely. Otherwise, the fluorocarbon resin tape may not adhere properly.


**Installation
Procedure
(Continued)**

2. INSTALL FLUOROCARBON RESIN TAPE


- A. Place the fluorocarbon resin tape onto the seat belt as shown in the illustration.

NOTE:


Before installation of the fluorocarbon resin tape, it is necessary to pre-release the colored film about 5 mm for each side. (Not fully released.)




- B. By pulling up the seat belt, put the fluorocarbon resin tape through the hole of the shoulder belt anchor. Match the shoulder belt anchor to the center of the tape.



- C. Remove the upper side colored film from the fluorocarbon resin tape, and securely affix the tape to the outside of the shoulder belt anchor.



- D. Remove the lower side colored film from the fluorocarbon resin tape, and securely affix the tape to the outside of the shoulder belt anchor.



NOTE:

- Be sure to affix the fluorocarbon tape securely along all edges.
- Pay attention not to make any wrinkles or slack in the fluorocarbon resin tape.

- E. Remove the clip.

**Installation
Procedure**
(Continued)

- F. By pulling the seat belt up and down several times, as shown in the illustration, securely affix the fluorocarbon resin tape and confirm the smoothness of the belt movement.

NOTE:

Affix the fluorocarbon resin tape on the shoulder belt anchor to the other side following the same procedure.

NOTE:

If the seat belt requires cleaning to remove dirt, only use a neutral detergent or lukewarm water to clean. Use the seat belt after it is completely dried, to confirm proper operation.

