


CD SOUND SKIPS

INSPECTION PROCEDURE

1 DISC CLEANING



- (a) Disk cleaning
 (1) If the disk gets dirty, clean the disk by wiping the surface from the center to outside in the radial directions with a soft cloth.

NOTICE:

Do not use a conventional record cleaner or anti-static preservative.

Standard: malfunction disappear.

OK

DISC DIRTY

NG

2 REPLACE CD WITH ANOTHER AND RECHECK

- (a) Replace the CD with another and recheck.
 (1) Check the installation condition of the radio receiver assembly.
Standard: malfunction disappear.

OK

CD FAULTY

NG

3 CHECK WHEN THIS HAPPENS

- (a) Check when this happens.
 (1) Check that in what condition (place) noise occurs.
Standard: Driving on the bumpy road.

OK

Go to step 5

NG

4 COMPARE IT WITH ANOTHER CAR OF SAME MODEL

- (a) Compare it with another vehicle of the same model.
 (1) Compare with the vehicle of the same type which does not have a trouble to see if there is any difference in the condition of trouble occurrence.
Standard: No difference found.

OK

SETTING

NG

5	CHECK OF RADIO RECEIVER ASSEMBLY INSTALLATION
----------	--

- (a) Check of radio receiver assembly installation.
 (1) Check the installation condition of the radio receiver assembly.

Standard: Installed properly.

NG

INSTALL THE RADIO RECEIVER ASSEMBLY PROPERLY

OK

6	DID THE TEMPERATURE IN THE CABIN CHANGE RAPIDLY?
----------	---

- (a) Did the temperature in the cabin change rapidly?
 (1) Check whether or not the rapid temperature change occurred in the cabin.

Standard: The rapid temperature change occurred.

Reference:

The rapid temperature change creates condensation inside the CD player, which may disable playing CD.

OK

CONDENSATION DUE TO TEMPERATURE CHANGE(LEAVE IT AS IT IS FOR A WHILE BEFORE USING)

NG

CHECK AND REPLACE RADIO RECEIVER ASSY
--