

INSTALLATION

1. INSTALL SHOCK ABSORBER WITH COIL SPRING

- (a) Install the upper side of the shock absorber to the chassis frame with the 3 nuts.

Torque: 64 N·m (650 kgf·cm, 47 ft·lbf)

- (b) Connect the lower side of the shock absorber to the lower suspension arm with the bolt, washer and nut.

Torque: 135 N·m (1,400 kgf·cm, 100 ft·lbf)

2. INSTALL FRONT WHEEL

Torque: 110 N·m (1,150 kgf·cm, 83 ft·lbf)